

Ecooustic® Foot Controller



OVERVIEW

The Ecooustic® Series Footcontroller is the perfect companion to the Ecooustic E110 amplifier. It features both normal and stompbox modes with up to 8 presets. The Ecooustic Series Footcontroller also allows access to the onboard 30 second looper, a truly great feature! With Tap Tempo, Tune/Mute and Phase reverse switches, the Ecooustic Series Footcontroller will bring your Ecooustic amplifier to life!

FEATURES

- Unlocks 30 second looper on E110 and Session 300
- Normal and Preset Effects modes
- Up to 8 presets
- Tap Tempo button
- Looper controls
- Tune/Mute switch
- Phase reverse switch
- Use with the Ecooustic E110 and Session 300 amplifiers
- Weight Packed: 5.07 lb(2.3 kg)
- Width Packed: 7"(17.78 cm)
- Height Packed: 12.5"(31.75 cm)
- Depth Packed: 2.75"(6.985 cm)