

Spectrum Analog Filter Errata

This sheet provides corrections to several errors in the User's Manual.

PAGES 4&5

The Front panel drawing shows the increment/decrement buttons incorrectly. They should read, going from left to right, Decrement (down arrow) and Increment (up arrow), this is the reverse of what is illustrated.

PAGE 14

The initialization procedures are incorrect, they should read as follows:

To initialize:

1. Remove power from the Analog Filter.
2. Press and hold the **Decrement** (down arrow) button and the **EXEC** button while reapplying power. The display will show **b1**.

To initialize for CyberBass:

1. Remove power from the Analog Filter.
2. Press and hold the **Decrement** (down arrow) button and the **Bypass** button while reapplying power. The display will show **b2**.



Features and specifications subject to change without notice.

Peavey Electronics Corporation / 711 A Street / Meridian, MS 39302-2898 / U.S.A. // (601) 483-5365 Telex: 504115 / FAX (601) 486-1278
© 1994 Printed in the U.S.A. 80302284 11/94